

BECKHOFF New Automation Technology

Manual | EN

C6675-0060

Industrial PC



Table of contents

1	Notes on the documentation.....	5
2	For your safety	6
2.1	Signal words.....	6
2.2	Intended use	6
2.3	Fundamental safety instructions	7
2.4	Operator's obligation to exercise diligence.....	7
2.5	Notes on information security.....	8
3	Product overview	9
3.1	Structure.....	10
3.2	Interface description	11
3.2.1	Power supply.....	11
3.2.2	PS/2	13
3.2.3	RS232	14
3.2.4	DisplayPort.....	15
3.2.5	DVI	16
3.2.6	Ethernet RJ45	17
3.2.7	USB	18
3.2.8	Audio connections.....	19
3.3	Optional interfaces	20
3.3.1	C9900-E195 with 2 USB ports	21
3.3.2	C9900-E216 with 2 USB ports	21
3.3.3	C9900-E166 with 2 RS232 serial interfaces	22
3.3.4	C9900-E203 with 1 serial interface RS232	23
3.4	Name plate	24
3.5	TwinCAT version	25
4	Commissioning	26
4.1	Transport and unpacking	26
4.2	Control cabinet installation	27
4.3	Connecting the industrial PC.....	29
4.3.1	Grounding of the industrial PC.....	29
4.3.2	Connecting cables and power supply	31
4.4	Switching the industrial PC on and off	32
5	Configuration.....	34
5.1	Beckhoff Device Manager	34
5.2	UPS configuration	35
5.3	Wake on LAN (WOL)	37
6	Decommissioning	39
6.1	Disconnecting the power supply and cables	39
6.2	Disassembly and disposal.....	40
7	Maintenance	41
7.1	Cleaning	41
7.2	Maintenance.....	42
7.2.1	Access to device components.....	44

7.2.2 Replacing the battery 47

7.2.3 Replacing the storage media 48

7.2.4 Replacing the fan 51

8 Troubleshooting 55

9 Technical data 56

10 Appendix 57

10.1 Service and support 57

10.2 Approvals 58

1 Notes on the documentation

This description is intended exclusively for trained specialists in control and automation technology who are familiar with the applicable national standards.

The documentation and the following notes and explanations must be complied with when installing and commissioning the components.

The trained specialists must always use the current valid documentation.

The trained specialists must ensure that the application and use of the products described is in line with all safety requirements, including all relevant laws, regulations, guidelines, and standards.

Disclaimer

The documentation has been compiled with care. The products described are, however, constantly under development.

We reserve the right to revise and change the documentation at any time and without notice.

Claims to modify products that have already been supplied may not be made on the basis of the data, diagrams, and descriptions in this documentation.

Trademarks

Beckhoff®, ATRO®, EtherCAT®, EtherCAT G®, EtherCAT G10®, EtherCAT P®, MX-System®, Safety over EtherCAT®, TC/BSD®, TwinCAT®, TwinCAT/BSD®, TwinSAFE®, XFC®, XPlanar®, and XTS® are registered and licensed trademarks of Beckhoff Automation GmbH.

If third parties make use of the designations or trademarks contained in this publication for their own purposes, this could infringe upon the rights of the owners of the said designations.



EtherCAT® is a registered trademark and patented technology, licensed by Beckhoff Automation GmbH, Germany.

Copyright

© Beckhoff Automation GmbH & Co. KG, Germany.

The distribution and reproduction of this document, as well as the use and communication of its contents without express authorization, are prohibited.

Offenders will be held liable for the payment of damages. All rights reserved in the event that a patent, utility model, or design are registered.

Third-party trademarks

Trademarks of third parties may be used in this documentation. You can find the trademark notices here: <https://www.beckhoff.com/trademarks>.

2 For your safety

The signal words and their meanings are explained in the chapter on safety. They contain fundamental safety instructions that are essential for preventing personal injuries and damage to property.

Exclusion of liability

Beckhoff shall not be held liable in the event that this documentation is not complied with and the devices are therefore not used in line with the documented operating conditions.

2.1 Signal words

The signal words used in the documentation are classified below.

Warning on personal injuries

 DANGER
High-risk hazard that will result in death or serious injury.
 WARNING
Medium-risk hazard that may result in death or serious injury.
 CAUTION
Low-risk hazard that may result in minor injury.

Warning on property and environmental damage

NOTICE
The environment, equipment, or data may be damaged.

2.2 Intended use

The device is intended for use as a control system for automation, visualization and communication in machine and system engineering.

The device has been developed for an IP20 working environment. This involves finger protection and protection against solid foreign objects up to 12.5 mm. There is no protection against water. Operation of the devices in wet and dusty environments is not permitted.

The specified limits for technical data must be adhered to.

The device can be used within the documented operating conditions.

Improper use

Do not use the device outside the documented operating conditions.

2.3 Fundamental safety instructions

The following safety instructions must be observed when handling the device.

Application conditions

- Do not use the device under extreme environmental conditions.
- Do not use the device in hazardous areas.
- Never plug or unplug connectors during thunderstorms. There is a risk of electric shock.
- Ensure that the device has a protective and functional earth connection.

Damage to property, loss of data and impairment of functions

- If you change the hardware and software configurations, you must keep within the specified limits of power consumption and power loss (please refer to the respective data sheet).
- Ensure that only trained specialists with a control and automation engineering background, operate the device. Use by unauthorized persons can lead to damage to property and loss of data.
- Fuse the power supply line to protect the supply line in the event of a short circuit according to its cross-section.
- In case of fire, extinguish the device with powder or nitrogen.

2.4 Operator's obligation to exercise diligence

The operator must ensure that

- the products are used only for their intended purpose (see Chapter 2.2 [Intended use](#) [► 6]).
- the products are only operated in sound condition and in working order.
- the products are operated only by suitably qualified and authorized personnel.
- the personnel is instructed regularly about relevant occupational safety and environmental protection aspects, and is familiar with the operating instructions and in particular the safety instructions contained herein.
- the operating instructions are in good condition and complete, and always available for reference at the location where the products are used.

2.5 Notes on information security

The products of Beckhoff Automation GmbH & Co. KG (Beckhoff), insofar as they can be accessed online, are equipped with security functions that support the secure operation of plants, systems, machines and networks. Despite the security functions, the creation, implementation and constant updating of a holistic security concept for the operation are necessary to protect the respective plant, system, machine and networks against cyber threats. The products sold by Beckhoff are only part of the overall security concept. The customer is responsible for preventing unauthorized access by third parties to its equipment, systems, machines and networks. The latter should be connected to the corporate network or the Internet only if appropriate protective measures have been set up.

In addition, the recommendations from Beckhoff regarding appropriate protective measures should be observed. Further information regarding information security and industrial security can be found in our <https://www.beckhoff.com/secguide>.

Beckhoff products and solutions undergo continuous further development. This also applies to security functions. In light of this continuous further development, Beckhoff expressly recommends that the products are kept up to date at all times and that updates are installed for the products once they have been made available. Using outdated or unsupported product versions can increase the risk of cyber threats.

To stay informed about information security for Beckhoff products, subscribe to the RSS feed at <https://www.beckhoff.com/secinfo>.

3 Product overview

The industrial PC belongs to the series of powerful industrial PCs for control cabinet installation with ATX motherboard. The device is suitable for various applications and requirements.

Thanks to the available processors, the industrial PC can be used for the following applications, among others:

- various automation and visualization tasks
- a wide range of IoT tasks with data preprocessing
- complicated HMI applications
- extensive axis controllers
- short cycle times
- high-volume data handling

In its basic configuration, the device includes the following features:

- ATX motherboard
- Intel® processor
- DRAM SODIMM
- 3½-inch hard disk
- 2 x hard drive caddy for a 3½-inch hard disk
- 100-240 V AC power supply unit

3.1 Structure




Fig. 1: Structure

Table 1: Key - C6675 structure

No.	Component	Description
1	Mounting concept	Holes for mounting the industrial PC in the control cabinet
2	Connection compartment	Access to interfaces of the industrial PC
3	Name plate	Information on the equipment of the industrial PC
4	Housing cover	Access to exchangeable device components
5	Optional multi DVD drive	Read and write CDs and DVDs
6	Two hard drive caddies	Hard disks or SSDs

3.2 Interface description

In the basic configuration, the industrial PC includes the following interfaces:

- Power supply (X101)
- PS/2 mouse and keyboard (X103, X104)
- RS232 (X116)
- DisplayPort (X117)
- DVI (X114, X115)
- Ethernet RJ45 (X112, X113)
- USB (X108-X111)
- Audio connections (X120-X122)




Fig. 2: Connection section

3.2.1 Power supply

In its basic configuration, the industrial PC is equipped with a 100-240 V AC, 50-60 Hz full range power supply unit.

The following table lists the maximum current carrying capacity of the 100–240 V AC power supply:

Table 2: Current carrying capacity power supply unit

Output voltages power supply unit	Current load 100-240 V AC power supply unit max.
+3.3 V	20 A
+5 V	25 A
+12 V total	50 A
-12 V	0.5 A
+5 V stand by	3.0 A

The total power output of the +3.3 V and +5 V lines must not exceed 100 W. The maximum total current for the +12 V outputs must not exceed 50 A.

The power supply is connected via the IEC socket (X101) on the top of the industrial PC. The assignment includes a protective conductor (1), a neutral conductor (2) and an outer conductor (2).




Fig. 3: IEC socket

3.2.2 PS/2

The industrial PC has two PS/2 interfaces (X103, X104). The upper interface (X104) allows the connection of a PS/2 mouse, the lower interface (X103) allows the connection of a PC keyboard. The connection is made via standard MiniDIN connectors.




Fig. 4: PS/2 mouse and keyboard

Table 3: PS/2 interface mouse pin assignment

Pin	Name	Description
B1	MDAT	Mouse Data
B2	N/C	Reserved
B3	GND	Ground
B4	(S)VCC	5 V supply voltage
B5	MCLK	Mouse Clock
B6	N/C	Reserved

Table 4: PS/2 interface keyboard pin assignment

Pin	Name	Description
A1	KDAT	Keyboard data
A2	MDAT	Mouse Data
A3	GND	Ground
A4	(S)VCC	5 V supply voltage
A5	KCLK	Keyboard Clock
A6	MCLK	Mouse Clock

3.2.3 RS232

The serial interface COM1 (X116) is led out via a 9-pin standard DSUB connector. The signals comply with the RS232 standard. The port address and the used interrupt are configured automatically, but can also be set manually with the help of the BIOS setup if required.




Fig. 5: RS232 interface pin numbering

Table 5: RS232 pin assignment

Pin	Signal	Description
1	DCD	Data Carrier Detect
2	RxD	Receive Data
3	TxD	Transmit Data
4	DTR	Data Terminal Ready
5	GND	Ground
6	DSR	Data Set Ready
7	RTS	Request to Send
8	CTS	Clear to Send
9	RI	Ring Indicator

3.2.4 DisplayPort

The industrial PC has a DisplayPort (X117) that enables connection of devices with DisplayPort. Additionally, DVI signals can be transmitted via an adapter cable. The following ordering option is available to you for this purpose:

- C9900-Z468: adapter cable DisplayPort to DVI, 40 cm




Fig. 6: DisplayPort pin numbering

Table 6: Pin assignment of DisplayPort

Pin	Connection	Pin	Connection
1	LVDS lane 0 +	2	Ground
3	LVDS lane 0 -	4	LVDS lane 1 +
5	Ground	6	LVDS lane 1 -
7	LVDS lane 2 +	8	Ground
9	LVDS lane 2 -	10	LVDS lane 3 +
11	Ground	12	LVDS lane 3 -
13	Config 1	14	Config 2
15	AUX channel +	16	Ground
17	AUX channel -	18	Hot-plug detection
19	Power supply: ground	20	Power supply: 3.3 V / 500 mA

3.2.5 DVI

The industrial PC has two DVI connections (X114, X115), to which a DVI-capable monitor can be connected. Only digital signals are transmitted.




Fig. 7: DVI interface pin numbering

Table 7: DVI interface pin assignment

Pin	Connection	Pin	Connection	Pin	Connection
1	TMDS Data 2 -	9	TMDS Data 1 -	17	TMDS Data 0 -
2	TMDS Data 2 +	10	TMDS Data 1 +	18	TMDS Data 0 +
3	TMDS Data 2/4 Shield	11	TMDS Data 1/3 Shield	19	TMDS Data 0/5 Shield
4	not connected	12	not connected	20	not connected
5	not connected	13	not connected	21	not connected
6	DDC Clock	14	+ 5 V Power	22	TMDS Clock Shield
7	DDC Data	15	Ground (+ 5 V, Analog H/V Sync)	23	TMDS Clock +
8	Analog Vertical Sync	16	Hot Plug Detect	24	TMDS Clock -

3.2.6 Ethernet RJ45

The industrial PC has two Gigabit LAN ports (X112, X113). The 100Base-T and 1000Base-T Ethernet standards enable the connection of corresponding network components and data rates of 100/1000 Mbit/s. The required speed is selected automatically.

The RJ45 connection technology with twisted-pair cables is used. The maximum length of the cable connection is 100 m. The industrial PC may only be connected to internal Ethernet networks and not to external telecommunication networks.

If you use the Ethernet ports with EtherCAT or for Real-Time Ethernet applications, you must observe the following distinction:

The Ethernet port (X113, LAN2) connected via PCIe® with the i210 controller is generally suitable for cycle times ≤ 1 ms and for distributed clock applications with EtherCAT.

The Ethernet port (X112, LAN1) integrated in the chipset with the i219 controller is generally suitable for EtherCAT and real-time Ethernet applications with cycle times > 1 ms (without distributed clocks).




Fig. 8: Ethernet interface pin numbering

Table 8: Ethernet interface pin assignment

Pin	Signal	Description
1	T2 +	Pair 2
2	T2 -	
3	T3 +	Pair 3
4	T1 +	Pair 1
5	T1 -	
6	T3 -	Pair 3
7	T4 +	Pair 4
8	T4 -	

The LEDs of the LAN interfaces indicate the activity and the data transmission rate (Mbit/s). The LED shown completely green in the figure indicates whether the interface is connected to a network. If this is the case, the LED lights up green. The LED flashes when data transmission is in progress on the interface.

The green/orange LED shown in the figure indicates the data transmission rate. If the speed is 100 Mbit/s the LED is orange, at 1000 Mbit/s it is green.

3.2.7 USB

The industrial PC has four USB 3.0 interfaces (X108-X111). They are used to connect peripheral devices with USB interfaces. Each of the interfaces supplies 900 mA current and is electronically protected.




Fig. 9: USB interface pin numbering

Table 9: USB interface pin assignment

Pin	Connection
1	Vbus
2	D -
3	D +
4	GND
5	StdA_SSRX -
6	StdA_SSRX +
7	GND_DRAIN
8	StdA_SSTX -
9	StdA_SSTX +

3.2.8 Audio connections

The industrial PC has three audio connections with the Line In (X122), Line Out (X121) and microphone input (X120) sockets.




Fig. 10: Audio connections

The three sockets are brought out for 3.5 mm jack plugs. The pins of the jack plugs are assigned as follows:




Fig. 11: Jack plug pin assignment

Table 10: Jack plug pin assignment

Pin	Connection
L	Left sound signal
R	Right sound signal
GND	Common ground (return)

3.3 Optional interfaces

Interface options are available to extend your industrial PC with additional interfaces beyond the basic configuration.

Table 11: Interface options

Ordering option	Description	Link to option
C9900-E195	2 USB ports	https://www.beckhoff.com/c66xx Select a PC, then the product variant, and then the "Options" tab at the bottom of the website.
C9900-E216	2 USB ports	
C9900-E166	2 serial interfaces RS232	
C9900-E203	1 RS232 serial interface	

Table 12: Module options

Ordering option	Description	Link to option
C9900-E209	Module for electrical isolation of an RS232 interface	https://www.beckhoff.com/c66xx Select a PC, then the product variant, and then the "Options" tab at the bottom of the website.
C9900-E210	Module for converting an RS232 interface to RS485	
C9900-E211	Module for converting an RS232 interface to RS422	

To be able to use the listed modules, you also need suitable slot or connector brackets. The corresponding bracket can only be ordered in combination with one of the modules.

Table 13: Slot options

Ordering option	Description	Link to option
C9900-M568	Slot bracket for a serial interface module	https://www.beckhoff.com/c66xx Select a PC, then the product variant, and then the "Options" tab at the bottom of the website.
C9900-M569	Slot bracket for two serial interface modules	

3.3.1 C9900-E195 with 2 USB ports

The option includes two USB 2.0 interfaces. They are used to connect peripheral devices with USB connector.




Fig. 12: USB interface pin numbering

Table 14: USB interface pin assignment

Pin	Connection
1	Vbus
2	D -
3	D +
4	GND

3.3.2 C9900-E216 with 2 USB ports

The option includes two USB 2.0 interfaces. They are used to connect peripheral devices with USB connector.




Fig. 13: USB interface pin numbering

Table 15: USB interface pin assignment

Pin	Connection
1	Vbus
2	D -
3	D +
4	GND

3.3.3 C9900-E166 with 2 RS232 serial interfaces

The serial interfaces include two electrically isolated sockets. They are fed out via two 9-pin standard DSUB connectors. The interfaces provide an asynchronous, serial communication method defined in the RS232 standard.

The channels are protected by overvoltage protection.




Fig. 14: RS232 interface pin numbering

Table 16: RS232 interface pin numbering

Pin	Name	Description
1	DCD	Data Carrier Detect
2	RXD	Receive Data
3	TXD	Transmit Data
4	DTR	Data Terminal Ready
5	GND	Ground
6	DSR	Data Set Ready
7	RTS	Request to Send
8	CTS	Clear to Send
9	RI	Ring Indicator

3.3.4 C9900-E203 with 1 serial interface RS232

The serial interface contains an electrically isolated socket. It is led out via a 9-pin standard DSUB connector. The interface provides an asynchronous, serial communication method defined in the RS232 standard.

The channel features overvoltage protection.




Fig. 15: RS232 interface pin numbering

Table 17: RS232 interface pin numbering

Pin	Name	Description
1	DCD	Data Carrier Detect
2	RXD	Receive Data
3	TXD	Transmit Data
4	DTR	Data Terminal Ready
5	GND	Ground
6	DSR	Data Set Ready
7	RTS	Request to Send
8	CTS	Clear to Send
9	RI	Ring Indicator

3.4 Name plate

The name plate provides information on the equipment fitted to your industrial PC. The name plate shown here serves only as an example.




Fig. 16: Name plate

Table 18: Legend C6675 name plate

No.	Description
1	Vendor
2	Model: The last four digits indicate the device generation
3	Serial number = Beckhoff Traceability Number (BTN)
4	Date of manufacture
5	Mainboard
6	CPU
7	Main memory
8	Power supply
9	HDD/SSD
10	DVD drive
11	Storage media
12	MAC addresses of the Ethernet interfaces (X112, X113)
13	Optional interfaces
14	FCC approval
15	Address of the vendor
16	Symbols
17	Note: be sure to read the device manual.
18	Main switch for switching the PC on and off
19	Power supply connection
20	Connection section standard interfaces
21	Plug-in card slots for options

3.5 TwinCAT version

To ensure optimal performance and access to all the functions of your device when using the TwinCAT control software, Beckhoff recommends using the latest TwinCAT version. In addition, you should never go below the minimum requirement for the TwinCAT version. This consists of the hardware requirements and the general TwinCAT system requirements. The general TwinCAT system requirements can be found [here](#). The following table shows the minimum TwinCAT version required for the different device generations, depending on the operating system and based on the hardware requirements:

Table 19: C6675-0060 Minimum TwinCAT version

Operating system	Minimum TwinCAT version
Windows 10 64-bit	3.1 build 4024.12
Windows Server 2019	3.1 build 4024.12
Windows 11 64-bit	3.1 build 4026.16

4 Commissioning

To be able to use the industrial PC, you must first commission it. The first step is to transport the device to its operating location and unpack it. This is followed by installing the device in the control cabinet, connecting the cables and the power supply and finally switching on the industrial PC.

4.1 Transport and unpacking

Note the specified transport and storage conditions (see Chapter 9 [Technical data](#) [► 56]).

Despite the robust design of the unit, the components are sensitive to strong vibrations and impacts. During transport the device must therefore be protected from mechanical stress. Appropriate packaging of the device, such as the original packaging, can improve the vibration resistance during transport.

NOTICE

Hardware damage due to condensation

Unfavorable weather conditions during transport can cause damage to the device.

- Protect the device against moisture (condensation) during transport in cold weather or in case of extreme temperature fluctuations.
- Do not put the device into operation until it has slowly adjusted to the room temperature.
- Should condensation occur, wait for about 12 hours before switching the device on.

4.2 Control cabinet installation

NOTICE

Extreme environmental conditions

Extreme environmental conditions can cause damage to the device.

- Avoid extreme environmental conditions.
- Protect the device against dust, moisture and heat.

NOTICE

Incorrect installation

Incorrect installation in a control cabinet prevents air circulation in the device and causes impaired functioning.

- Only install the device in the orientation specified below.

The device is designed for installation inside a control cabinet in machine and system engineering. The environmental conditions specified for operation must be observed.

You can use the mounting concept on the back side of the industrial PC to mount the device in the control cabinet. Only install the device in the control cabinet with the interfaces facing upwards.




Fig. 17: Mounting concept

The dimensions of the industrial PC are used to prepare the control cabinet and to mount the device correctly in the control cabinet.

All dimensions are in mm.




Fig. 18: Dimensions

Installation in the control cabinet

When installing in the control cabinet, note that there must be 5 cm of free space above and below the device for ventilation.

To mount the industrial PC in the control cabinet, you must make sure that there are holes for the fastening screws in the control cabinet that fit the device dimensions of the PC (see above). You need M4 screws for mounting.

After you have drilled the holes for the fastening screws in the control cabinet, you can mount the industrial PC in the control cabinet.




Fig. 19: Control cabinet installation

To install the industrial PC in the control cabinet, follow the steps below:

1. Insert the fastening screws into the drill holes in the control cabinet.
 2. Hang the PC on the screws at the points marked of the mounting concept.
 3. Tighten the fastening screws.
- ⇒ You have successfully installed the industrial PC in the control cabinet.

4.3 Connecting the industrial PC

⚠ CAUTION

Risk of electric shock

Dangerous touch voltages can lead to electric shock. To avoid electric shock, observe the following:

- Never connect or disconnect the device cables during a thunderstorm.
- Provide protective earthing for handling the device.

To prepare the industrial PC for operation, it must be connected. The first step is to ground the device. Then you can connect the cables and the power supply.

The industrial PC is equipped with a 100-240 V AC, 50-60 Hz full-range power supply unit.

4.3.1 Grounding of the industrial PC

Potential differences are minimized and electrical currents are diverted to the ground through grounding or potential equalization of electronic devices. This is to prevent dangerous touch voltages and electromagnetic interference.

The protection provided by the devices may be impaired by non-intended use.

All connected devices must be in SELV (Safety Extra Low Voltage)/PELV (Protective Extra Low Voltage) circuits.

Protective earth

The protective grounding of a device serves to avoid dangerous touch voltages. According to the EN 60204-1 standard (Chapter 8 Potential equalization), protective grounding is required if:

- the device exceeds dimensions of 50 mm x 50 mm,
- the device can be touched or encompassed over a large area,
- contact between the device and active parts is possible,
- an insulation fault may occur.

A protective conductor is included in the industrial PC's IEC socket for connecting the power supply. Establish the low-resistance protective earth of the industrial PC via the voltage connection, thus avoiding dangerous touch voltages.

EMC

NOTICE

Hardware damage due to electromagnetic interference

The use of the device without a functional earth can lead to material damage due to electromagnetic interference.

- Only use the device with functional earth.

Electromagnetic compatibility (EMC) of the device includes on the one hand not affecting other devices and equipment by electromagnetic interference and on the other hand not being disturbed by electrical or electromagnetic effects itself.

To do this, the device must comply with certain protection requirements. The device has EMC interference immunity according to EN 61000-6-2. The EMC interference emission of the device meets the requirements of EN 61000-6-4.

The functional earth is necessary for the EMC of the device. You establish functional earthing via the grounding connection between the grounding bolt in the connection section on the top of the industrial PC (see Fig.) and the central grounding point of the control cabinet in which the PC is installed. Use either a wide, flat earthing strap or a round conductor with a minimum cross-section of 10 mm² for the earth connection. In the case of a round conductor, also use a cable lug with a ring and place the ring over the earthing bolt.




Fig. 20: Grounding bolt for functional earthing

4.3.2 Connecting cables and power supply

NOTICE

Incorrect connection procedure

Incorrect procedure when connecting the cables and the power supply can cause hardware damage.

- Follow the documented procedure for connecting the cables and the power supply.
- Always connect the cables first and only then switch on the power supply.
- Please read the documentation for the external devices prior to connecting them.

Connecting cables

The connections are located on the top side of the industrial PC. They are documented in chapter 3.1 [Structure](#) [► 10].

Make sure that you first connect the functional earth to the grounding bolt of the PC (see chapter 4.3.1 [Grounding the industrial PC](#) [► 29]) and then plug in all data transmission lines.

Connect power supply via 100-240 V AC power supply unit

For the connection of the power supply, there is an IEC socket in the connection compartment on the top of the device. To connect the industrial PC to the power supply, use the supplied IEC power cable with a German Schuko plug at the end.

In the USA and Canada, the connection cable must meet the following specifications depending on the power supply:

- Separable supply cable of a max. length of 4.5 m (14.76 ft.) of type SJT or SVT (min. 125 V, 10 A), plug with ground connection according to NEMA 5-15P/-20P or IEC plug on the device side.
- Separable supply cable of a max. length of 4.5 m (14.76 ft.) of type SJT or SVT (min. 250 V, 10 A), plug with ground connection according to NEMA 6-15P/-20P or IEC plug on the device side.

Proceed as follows to connect the 100-240 V AC power supply unit:

1. Check that the mains voltage is correct.
2. Plug the corresponding IEC power cable into the IEC socket of the industrial PC.
3. Connect the industrial PC to a Schuko socket.

4.4 Switching the industrial PC on and off

NOTICE

Public networks

Connecting the device to public networks without additional protective measures can compromise the safety of the device.

- Protect the device before connecting it to public networks.

NOTICE

Data loss due to switching off the device while the software is running

Switching off the device before the running software is terminated and the operating system is shut down can lead to data loss.

- Quit the running software and shut down the operating system before switching off the device.

NOTICE

Data loss due to switching off the power supply when the UPS battery is empty

Switching off the power supply when the UPS battery is empty can lead to data loss, as the operating system cannot be shut down properly without battery power.

- Ensure that the UPS battery is charged in the event of a power failure.
- For UPS C9900-P209 and C9900-U209, charge the battery exclusively via the switched-on PC. Never connect a charger.

NOTICE

Shortened battery life due to switching off the power supply

If the power supply is simply switched off, the operating system shuts down via the battery. With daily use, this significantly shortens the life of the battery.

- Avoid switching off the power supply before shutting down the operating system.
- Use the PC-ON input (see the following description) to shut down the operating system in a battery-friendly manner.

Switch on and off with 100-240 V power supply

The industrial PC is started or switched off when the system is switched on or off or when the power supply to the industrial PC is connected or disconnected.

If you have ordered your industrial PC with a 110 V or 230 V UPS, this enables data backup in the event of a sudden switch-off of the device. If the power supply or the system is switched off before you have shut down the operating system properly, the operating system shuts down using the battery. Data can be saved. With frequent use, this shortens the life of the battery.

Driver installation

When you switch on the device for the first time, the optionally pre-installed operating system will be started. For any additional hardware you have connected, you have to install the drivers yourself afterwards. In addition, the Beckhoff Device Manager starts automatically. The Device Manager is a software from Beckhoff that supports you in configuring the device.

If you have ordered the device without an operating system, you must install this and the driver software for the additional hardware you have connected and for the components inside the device. Please follow the instructions in the documentation for the operating system and the additional components.

UPS software components

The UPS software components with the corresponding drivers must be installed on the PC in order to operate the power supply unit as a UPS. The software components and drivers are already installed on delivery of the PC with operating system. If they are not, you have to install the installation package *Beckhoff UPS* yourself.

You can obtain the installation package from Beckhoff Service (service@beckhoff.com). You then use the installation package to install the UPS software components. The UPS software components come with a detailed help function. Call up the help files either directly from the configuration register by clicking the Help button or start the file under *Start > Programs > Beckhoff > UPS software components*.

5 Configuration

The configuration chapter gives you an insight into the Beckhoff Device Manager and the UPS configuration as well as the Wake on LAN (WOL) function. The UPS configuration is relevant if you ordered your device with a UPS.

The Beckhoff Device Manager is a tool for detailed system diagnostics of hardware and software components. The procedure after the first start and after manually starting Beckhoff Device Manager is explained.

In the UPS configuration, assign the appropriate UPS to the device.

Using the Wake on LAN (WOL) function, you can switch on your device remotely.

5.1 Beckhoff Device Manager

The Beckhoff Device Manager enables detailed system diagnostics with uniform secure access to the existing hardware and software components. System data is recorded, analyzed and evaluated during operation. The data helps to detect deviations at an early stage and prevent device downtimes.

The user interface screenshots shown in this chapter are examples only and do not represent the actual state of your device.

The Beckhoff Device Manager always starts automatically after the device has been booted. In addition, you have the option of manually starting the previously closed Device Manager at any time.

The device is supplied with predetermined access data by default:

- User name: Administrator
- Password: 1

You also have the option of using the Beckhoff Device Manager to remotely configure the device via a web browser. More detailed information is available in the Beckhoff Device Manager [manual](#).

First start of Beckhoff Device Manager

When your device is booted for the first time, the Beckhoff Device Manager also starts automatically for the first time. The Security Wizard opens. It informs you that you should reset the default password set by Beckhoff. Proceed as follows:

1. Click **Next** on the Security Wizard start page.
⇒ This will take you to the **Change Passwords** page:

Fig. 21: Beckhoff Device Manager – Change passwords

2. Enter the access data of the Device Manager on delivery.
3. Choose a secure new password. Instructions for choosing a secure password are given below.

4. Confirm the changes by clicking on the tick in the red box on the right.
 5. Exit the Security Wizard.
- ⇒ You have reached the Device Manager start page.




Fig. 22: Beckhoff Device Manager – Start page

Continue to navigate in the menu and to configure the device. Note that modifications only become active once they have been confirmed.

Manual start of Beckhoff Device Manager

To start the Beckhoff Device Manager manually, proceed as follows:

1. Open a web browser locally on the device.
2. Enter *localhost/config* in the web browser to start the Beckhoff Device Manager.

⇒ The Beckhoff Device Manager starts. The Security Wizard appears.

Secure passwords

Strong passwords are an important prerequisite for a secure system.

Beckhoff supplies the device images with standard user names and standard passwords for the operating system. It is imperative that you change these.

Controllers are shipped without a password in the UEFI/BIOS setup. Beckhoff recommends assigning a password here as well.

Please note the following:

- Passwords should be unique for each user and service.
- Only change passwords after an incident in which passwords have become known without authorization.
- Train the device users in the use of passwords.

A secure password has the following characteristics:

- Password complexity: The password should contain capital and lower-case letters, numbers, punctuation marks and special characters.
- Password length: The password should be at least 10 characters long.

5.2 UPS configuration

Once you have installed the installation package with the UPS software components, you can configure the UPS. To start the configuration, go to *Start -> Beckhoff -> UPS Configuration*.

After starting the configuration, follow the steps below:

1. Click *Select*.




Fig. 23: Select UPS

2. Select the manufacturer *Beckhoff* from the drop-down menu.




Fig. 24: Select manufacturer

3. Select at Model/Interface *Beckhoff P24Vxxxx*.
4. Select the port *COM4*.
5. Click *Finish*.




Fig. 25: Select model/interface & port

6. Click *Apply*.




Fig. 26: Apply configuration

⇒ You have configured the UPS. The status of the connected UPS is displayed.




Fig. 27: UPS status

5.3 Wake on LAN (WOL)

Wake on LAN (WOL) allows you to turn on your device remotely when it receives a special network signal. WOL is enabled by default in Beckhoff standard images. You can configure this function in the operating system.

Configuration under Windows

To configure the Wake on LAN function, follow these steps:

1. Open the Device Manager.
2. Navigate to the **Network adapters** section.
3. Double-click the appropriate Ethernet controller.
 - ⇒ A window containing the Ethernet controller's properties will open.
4. Klick on the **Advanced** tab.
5. Set the **Wake on Magic Packet** and **Wake on Magic Packet from S5** properties to **Enabled**.
6. Confirm with **OK**.




Fig. 28: Activate function

7. Click the **Power Management** tab.
8. Check the box next to **Allow this device to wake the computer**.
9. Confirm with **OK**.




Fig. 29: Enable Function

⇒ You have configured the Wake on LAN function.

6 Decommissioning

NOTICE

Hardware damage due to power supply

A connected power supply can cause damage to the device during disassembly.

- Disconnect the power supply from the device before starting to disassemble it.

When taking the industrial PC out of operation, you must first disconnect the power supply and cables. You can then remove the device from the control cabinet.

If you do not wish to use the industrial PC any further, chapter 6.2 [Disassembly and disposal](#) [► 40] provides information on the correct disposal of the device.

6.1 Disconnecting the power supply and cables

⚠ CAUTION

Risk of electric shock

Dangerous touch voltages can lead to electric shock. To avoid electric shock, observe the following:

- Never connect or disconnect the device cables during a thunderstorm.
- Provide protective earthing for handling the device.

Before you remove the industrial PC from the control cabinet, you must disconnect the cables and the power supply.

Disconnecting the power supply

Proceed as follows to disconnect the 100-240 V AC power supply:

1. Disconnect the PC from your power supply.
2. Pull the voltage connector out of the IEC socket of the PC.

Disconnecting cables

To disconnect the cables from the industrial PC, proceed as follows:

1. Make a note of the wiring configuration, if you wish to restore it with another device.
2. Disconnect the data transmission cables from the industrial PC.
3. Finally, disconnect the grounding strap.

6.2 Disassembly and disposal

In order to be able to dismount the industrial PC from the control cabinet, you must first have disconnected the power supply and the cables (see Chapter 6.1 [Disconnecting the power supply and cables](#) [► 39]).

To remove the industrial PC from the control cabinet, proceed as follows:

1. Loosen the fastening screws just enough so that they remain attached to the control cabinet.
2. Lift the PC far enough so that the fastening screws slip into the keyholes.
3. Remove the PC from the control cabinet.

⇒ You have successfully dismounted the industrial PC.




Fig. 30: Positions of the fastening screws

Disposal of the industrial PC

Be sure to observe the national electronic scrap regulations when disposing of the industrial PC.

In order to dispose of the device, it must be removed and fully dismantled. Dispose of the components in the following way:

- Send plastic parts (polycarbonate, polyamide (PA6.6)) for plastics recycling.
- Take metal parts to the metal recycling collection point.
- Electronic parts such as fans and circuit boards must be disposed of in accordance with national electronic scrap regulations.
- Stick insulating tape over the poles of the CR2032 battery on the motherboard and dispose of the battery via the local battery recycling.

7 Maintenance

⚠ CAUTION

Risk of electric shock

Working on the device when live can lead to electric shock.

- Switch off the power supply before replacing device components. This does not apply to the replacement of storage media in a RAID configuration.

Maintenance measures increase the efficiency of the device by ensuring long-term functionality. Cleaning and maintenance by replacing certain device components contribute to this.

7.1 Cleaning

NOTICE

Unsuitable cleaning agents

The use of unsuitable cleaning agents can damage the device.

- Clean the device only as specified.

It is essential to observe the following aspects when cleaning the industrial PC:

- Make sure that no dust gets into the PC.
- Always keep the ventilation grilles free.
- Only use a vacuum cleaner to clean the PC. The industrial PC does not have to be switched off for this.
- Never use compressed air to clean the PC.

7.2 Maintenance

NOTICE

Use of incorrect spare parts

The use of spare parts not ordered from Beckhoff Service can lead to unsafe and faulty operation.

- Only use spare parts that you have ordered from Beckhoff Service.

Beckhoff devices are manufactured from components of the highest quality and robustness. They are selected and tested for best interoperability, long-term availability and reliable function under the specified environmental conditions.

Nevertheless, some components of the devices may be subject to a limited service life if they are operated under certain conditions, such as at increased ambient temperatures during operation or during storage or during long periods of storage out of operation.

Beckhoff therefore recommends replacing some of the components of the devices after the time after which predictions of the remaining service life of such components can no longer be reliably calculated.

The following table provides recommendations for the regular, precautionary replacement of the device components:

Table 20: Device component replacement recommendations

Component	Recommendation for replacement intervals (years)
UPS battery pack	5 years
2.5-inch hard disk	5 years or after 20,000 operating hours at more than 40 °C or after 30,000 operating hours at less than 40 °C
3.5-inch hard disk	5 years, irrespective of the operating hours
Fan	7 years
CFast, SSD, MicroSD, Compact Flash	10 years
Motherboard battery	5 years

Beckhoff is excluded from liability in the event of possible damage occurring during maintenance work. In order to avoid damage caused by electrostatic discharge when replacing device components, protective measures are recommended. Below are some suggestions.

ESD protection

NOTICE

Electrostatic discharge

The replacement of device components without ESD protection can lead to functional impairment and destruction of the device.

- If possible, apply ESD protection measures during maintenance work.

When working on electronic devices, there is a risk of damage due to ESD (electrostatic discharge), which can impair the function or destroy the device.

Protect the device and create an ESD-protected environment in which existing electrostatic charges are safely discharged to ground and charging is prevented.

An ESD-protected environment can best be created by setting up ESD protection zones. The following measures serve this purpose:

- ESD-compliant floors with sufficient conductivity to the reference potential PE;
- ESD-compatible work surfaces such as tables and shelves;
- Wrist grounding strap, especially for sedentary activities;
- grounded and electrostatically dissipating equipment and operating materials (e.g. tools) within the ESD protection zone.

If it is not possible to create an ESD protection zone, you can still protect the device against ESD damage. For example, the following measures can be used:

- Use conductive mats connected to the ground potential as underlays.
- Dissipate possible charges from your own body by touching grounded metal (e.g. control cabinet door).
- Wear a wrist grounding strap.
- Only remove new electronic components from the ESD packaging (tinted plastic bag) after putting on the wrist grounding strap.
- Do not walk around with electronic components in your hand if they are not in ESD packaging.

7.2.1 Access to device components

To be able to replace certain device components, you must first gain access to the interior of the industrial PC.

If your device with generation -0060 contains an NVMe™ M.2 SSD, you may only replace it if you have previously shut down and switched off the device.

To do this, follow the steps:

1. Pull the release handle upward to release the housing cover lock (section A).
2. Pull the housing cover forward by the handle until it moves freely at the bottom (section B). While doing so, hold the cover firmly so that it does not fall off.




Fig. 31: Unlocking the housing cover

3. Guide the housing cover downwards out of the guides (section C).
4. Loosen the knurled screw (1) of the card locating holder (2) (section D).




Fig. 32: Access to the interior of the device

5. Remove the card locating holder from the housing.
- ⇒ You now have access to the interior of the industrial PC.

To reinstall the card locating holder afterwards, follow the steps below:

1. Release all plastic elements of the card locating holder (section A).
2. Place the card locating holder again in the slots provided in the industrial PC (section B).
3. Keep the card locating holder pressed onto the edge of the industrial PC while tightening the knurled screw again (section C).




Fig. 33: Mounting the card locating holder

4. For each plug-in card, press down the associated plastic element of the card locating holder until the plug-in card is firmly seated in its slot.
- ⇒ You have mounted the card locating holder.

To reassemble the housing cover to the PC, you must push the inner hooks (1) of the housing cover into the guides (2) of the housing.




Fig. 34: Hooks and guides

To do this, follow the steps below:

1. Hold the cover inclined and place it below the housing (section A).

2. Push the cover up as far as possible, inserting the hooks of the cover into the guides of the housing (2) (section B).
 3. Place the cover into a straight position against the housing until the release handle snaps back into place (section C).
- ⇒ You have mounted the cover on the housing.




Fig. 35: Mounting the housing cover

7.2.2 Replacing the battery

⚠ WARNING

Incorrect battery type

Using a different type of battery can lead to a fire or explosion.

- Only replace the battery with a type R/C (BBCV2) battery, article number RC2032, nominal voltage 3 V.
- When replacing the battery, make sure that the polarity is correct.

⚠ WARNING

Incorrect handling of the battery

Handling the motherboard battery incorrectly can cause an explosion.

- Do not recharge the battery.
- Do not disassemble the battery.
- Do not dispose of the battery in fire.
- Do not open the battery.
- Protect the battery against direct sunlight and moisture.

NOTICE

Failure of the electronics due to mechanical damage

Scratches or damaged components on PCBs can cause the electronics to fail.

- Be very careful when replacing the battery and avoid mechanical damage to the electronics.

The device does not contain a lithium-ion battery. The motherboard battery is a CR2032 lithium-metal cell. It is used to supply power to the clock integrated on the motherboard. If the battery is depleted or missing, the date and time are displayed incorrectly.

Table 21: Technical data of the battery

Battery type	Electrical properties (at 20 °C)		Dimensions		
	Nominal voltage	Nominal capacity	Diameter	Height	Weight
CR2032	3.0 V	225 mAh	20.0 mm	3.20 mm	3.1 g

Chapter 7.2.1 [Access to device components](#) [► 44] shows how to access the battery.

To change the battery, proceed as follows:

1. Bend the hook on the battery holder slightly outward (section A).
2. Pull the battery out of the holder with needle-nose pliers (section B).




Fig. 36: Replacing the battery

3. Insert the new battery into the holder. Make sure that the polarity is correct, as shown.
- ⇒ You have successfully replaced the battery.

Battery disposal

To dispose of the battery, remove it, tape off the poles and put it in the battery disposal.

7.2.3 Replacing the storage media

Disposal of storage media

Delete confidential or technologically important data from the storage media before disposing of it. If a storage medium is defective, you must destroy it mechanically to prevent access to the data.

The old storage media must be disposed of in accordance with the national electronic waste regulations.

For new storage media, please contact your Beckhoff Sales only. Hard disks from Beckhoff are optimized for industrial applications. SSDs from Beckhoff have a considerably higher lifetime expectancy than commercially available SSDs.

Data transmission before replacement

If you want to exchange a storage medium according to Beckhoff's recommendation, you must copy the data from the old to the new storage medium. You can use the Beckhoff Service Tool (BST) for this purpose. BST is a graphical backup and restore program for devices with a Windows operating system. You can create an image of your operating system and use it to back up the operating system. Then you can restore the created image to a new data carrier. The BST is available on a bootable BST USB flash drive. This includes Windows and a backup tool. Select the size of the BST USB flash drive according to the size of the backup copy of your operating system. You can then keep the flash drive as a backup copy. For this purpose, the BST USB flash drives are designed for particularly long data preservation by means of special flash. For more information on the function of the BST, please refer to the corresponding [manual](#).

If your storage medium is defective and there is no backup, Beckhoff Service can provide you with a fresh Windows image. For this to be possible, your Beckhoff device must already have been delivered with a valid operating system license. After installing the fresh image, the applications must be reinstalled.

Hard disk replacement

Proceed as follows to change the hard disk:

1. Unlock the hard drive caddy with the corresponding key (section A).
2. Pull the key of the hard drive caddy to unlock it (section B).




Fig. 37: Open hard drive caddy

3. Open the hard drive caddy (section C).
⇒ The hard disk is pushed out of the hard drive caddy.
4. Pull the hard disk out of the hard drive caddy (section D).




Fig. 38: Hard disk removal

5. Insert the new hard disk into the hard drive caddy with the manufacturer's sticker facing upwards.
 6. Close the hard drive caddy again.
 7. Lock the hard drive caddy again.
- ⇒ You have replaced the hard disk.

SSD replacement

If you have ordered your device with an SSD instead of a hard disk, you have to proceed as follows when replacing the SSD:

1. Unlock the hard drive caddy with the corresponding key (section A).
2. Pull the key of the hard drive caddy to unlock it (section B).




Fig. 39: Open hard drive caddy

3. Open the hard drive caddy (section C).
4. Pull the SSD out of the hard drive caddy by the protruding Beckhoff sticker (section D).




Fig. 40: Removal SSD

5. Reinsert the new SSD in the same orientation.
 6. Close the hard drive caddy again.
 7. Lock the hard drive caddy again.
- ⇒ You have replaced the SSD.

7.2.4 Replacing the fan

NOTICE

Incorrect fan type

The device may be damaged if the wrong type of fan is installed.

- Only replace the fans with replacement fans from Beckhoff Service.

The fans ensure optimal cooling of the device. Order replacement fans only from Beckhoff. Please get in touch with your Beckhoff sales contact.

Remove the housing cover of the industrial PC in advance to gain access to the fans (see chapter 7.2.1 [Access to device components](#) ► 44)).

To replace the fan cartridge on the bottom of the PC, follow the steps below:

1. Loosen the knurled screw on the underside of the PC (section A).
2. Turn the cartridge downwards (section B).




Fig. 41: Loosen the fan cartridge

3. Disconnect the supply cable of the fan from the motherboard.
4. Remove the cartridge to the front (section C).




Fig. 42: Removal of fan cartridge

5. Insert the new fan cartridge.
 6. Connect the supply cable to the motherboard.
 7. Flip the cartridge up.
 8. Tighten the knurled screw.
- ⇒ You have now replaced the fan cartridge.

To replace the fans on the top of the PC, follow the steps below:

1. Loosen each of the two M3x5 screws of the fan holders (section A). Hold the holders tightly while doing this so that they do not fall off.




Fig. 43: Loosen the fan holder

2. Disconnect the supply cable of the fan from the motherboard.
3. Remove the fan holders with the fans (section B).




Fig. 44: Remove the fan holders with fan

4. Insert the new fan holders with fans again.
 5. Connect the supply cable to the motherboard.
 6. Retighten the two M3x5 screws.
- ⇒ You have now replaced the fans.

The fans in the power supply unit cannot be replaced separately. Instead, you will need to have the entire power supply unit replaced. Please contact Beckhoff Service for this.

Exchange CPU cooler

You can also replace the CPU cooler on the motherboard. Contact Beckhoff Service for a new cooler.

To replace the CPU cooler, follow the steps below:

1. Turn the four locking elements in the direction of the arrow shown on them to unlock the cooler from the motherboard. (section A).




Fig. 45: CPU cooler unlocking

2. Disconnect the supply cable of the cooler from the motherboard.
3. Pull the cooler off the motherboard while pulling the locking elements out of the holes in the motherboard (section B).




Fig. 46: CPU cooler removal

4. Remove the residues of the old thermal compound from the surface of the CPU. Use a paper towel moistened with alcohol for this purpose. Avoid ESD damage by never using a textile cloth.
 5. Place the new cooler with the locking elements into the holes provided on the motherboard. Make sure that you press the locking elements down into the holes as far as they will go.
 6. Connect the supply cable to the motherboard.
 7. Turn the locking elements in the opposite direction of the arrows shown on them to lock the cooler onto the motherboard.
- ⇒ You have replaced the CPU cooler.

The old fan must be disposed of in accordance with the national electronic waste regulations.

8 Troubleshooting

Table 22: Troubleshooting

Fault	Cause	Measures
No function of the device	No power supply to the device Other cause	Check the power supply cable Call Beckhoff Service
The device does not boot fully	BIOS setup settings are incorrect Other causes	Check BIOS setup settings (load defaults) Call Beckhoff Service
The device boots, software starts, but control does not operate correctly	The cause of the error is the software or plant parts outside of the device	Call the machine and software manufacturer
USB error during access with TwinCAT via USB	Cycle times in TwinCAT set to 10 ms (default)	Increase the cycle times to between 50 ms and 80 ms

9 Technical data

Table 23: Technical data

Product designation	C6675
Dimensions (W x H x D)	410 x 480 x 201 mm
Weight	15 kg basic configuration
Supply voltage	100-240 V _{AC} , 50-60 Hz, max. 5 A
Power consumption	Data sheet power consumption and power loss in the download finder: https://www.beckhoff.com/en-en/support/download-finder/search-result/?download_group=691754572
Secure element	fTPM 2.0 enabled (see TPM manual)
Protection rating	IP20
Overvoltage category	II
Pollution degree	2
Protection class	I
Vibration resistance (sinusoidal vibration)	EN 60068-2-6: 10 to 58 Hz: 0.035 mm 58 to 500 Hz: 0.5 G (approx. 5 m/s ²) During reading of CD/DVD: EN 60068-2-6: 10 to 58 Hz: 0.019 mm 58 to 500 Hz: 0.25 G (approx. 2.5 m/s ²)
Shock resistance (shock)	EN 60068-2-27: 5 G (approx. 50 m/s ²), duration: 30 ms During reading of CD/DVD: 5 G (approx. 50 m/s ²), duration: 11 ms
EMC interference immunity	conforms to EN 61000-6-2
EMC interference emission	conforms to EN 61000-6-4
Permissible ambient temperature	+0 °C...+50 °C (operation) -25 °C...+65 °C (transport / storage)
Permissible air humidity	Maximum 95 %, no condensation
Transport and storage	The same values for air humidity and shock resistance are to be observed during transport and storage as in operation. The shock resistance during transport can be improved by means of suitably packing the industrial PC.

10 Appendix

In the appendix you will find information for servicing and details of the approvals that your device has.

10.1 Service and support

Beckhoff and its worldwide subsidiaries offer comprehensive service and support, providing fast and competent assistance for all issues relating to Beckhoff products and system solutions.

Beckhoff Service

The Beckhoff service center provides support in all forms of after-sales service:

- on-site service
- repair service
- spare parts service
- hotline service

Hotline: + 49 5246/963-460
email: service@beckhoff.com

If your device requires attention, please state its serial number, which you can find on the name plate.

Beckhoff Support

Support offers you comprehensive technical assistance to help you with the application of individual Beckhoff products, and also with other extensive services:

- world-wide support
- design, programming, and commissioning of complex automation systems
- extensive training program for Beckhoff system components

Hotline: + 49 5246/963-157
email: support@beckhoff.com

Headquarters

Beckhoff Automation GmbH & Co. KG
Hülshorstweg 20
33415 Verl
Germany

Phone: + 49 5246/963-0
email: info@beckhoff.de

The addresses of the worldwide Beckhoff branches and agencies can be found on our website at <http://www.beckhoff.com/>.

You can also find further documentation for Beckhoff components there.

10.2 Approvals

Your device has at least the following approvals:

- CE
- FCC

You will find all other applicable approvals on the name plate of your device.

FCC approvals for the United States of America

FCC: Federal Communications Commission Radio Frequency Interference Statement

This device was tested and complies with the limits for a digital device of class A, according part 15 of the FCC regulations. These limits are designed to provide adequate protection against adverse interference, if the device is used in a commercial environment. This device generates, uses and may emit radio frequency energy and may cause adverse interference with radio communications, if it is not installed and used in accordance with the operating instructions. If this device is used in a residential area it is likely to cause adverse interference, in which case the user must take appropriate countermeasures in order to eliminate the interference at his own expense.

FCC approvals for Canada

FCC: Canadian Notice

This device does not exceed the class A limits for radiation, as specified by the Radio Interference Regulations of the Canadian Department of Communications.

List of figures

Fig. 1	Structure.....	10
Fig. 2	Connection section.....	11
Fig. 3	IEC socket.....	12
Fig. 4	PS/2 mouse and keyboard.....	13
Fig. 5	RS232 interface pin numbering.....	14
Fig. 6	DisplayPort pin numbering.....	15
Fig. 7	DVI interface pin numbering.....	16
Fig. 8	Ethernet interface pin numbering.....	17
Fig. 9	USB interface pin numbering.....	18
Fig. 10	Audio connections.....	19
Fig. 11	Jack plug pin assignment.....	19
Fig. 12	USB interface pin numbering.....	21
Fig. 13	USB interface pin numbering.....	21
Fig. 14	RS232 interface pin numbering.....	22
Fig. 15	RS232 interface pin numbering.....	23
Fig. 16	Name plate.....	24
Fig. 17	Mounting concept.....	27
Fig. 18	Dimensions.....	28
Fig. 19	Control cabinet installation.....	28
Fig. 20	Grounding bolt for functional earthing.....	30
Fig. 21	Beckhoff Device Manager – Change passwords.....	34
Fig. 22	Beckhoff Device Manager – Start page.....	35
Fig. 23	Select UPS.....	36
Fig. 24	Select manufacturer.....	36
Fig. 25	Select model/interface & port.....	36
Fig. 26	Apply configuration.....	37
Fig. 27	UPS status.....	37
Fig. 28	Activate function.....	38
Fig. 29	Enable Function.....	38
Fig. 30	Positions of the fastening screws.....	40
Fig. 31	Unlocking the housing cover.....	44
Fig. 32	Access to the interior of the device.....	44
Fig. 33	Mounting the card locating holder.....	45
Fig. 34	Hooks and guides.....	45
Fig. 35	Mounting the housing cover.....	46
Fig. 36	Replacing the battery.....	47
Fig. 37	Open hard drive caddy.....	48
Fig. 38	Hard disk removal.....	49
Fig. 39	Open hard drive caddy.....	49
Fig. 40	Removal SSD.....	50
Fig. 41	Loosen the fan cartridge.....	51
Fig. 42	Removal of fan cartridge.....	51
Fig. 43	Loosen the fan holder.....	52
Fig. 44	Remove the fan holders with fan.....	52

Fig. 45	CPU cooler unlocking.....	53
Fig. 46	CPU cooler removal	53

List of tables

Table 1	Key - C6675 structure	10
Table 2	Current carrying capacity power supply unit	11
Table 3	PS/2 interface mouse pin assignment.....	13
Table 4	PS/2 interface keyboard pin assignment.....	13
Table 5	RS232 pin assignment	14
Table 6	Pin assignment of DisplayPort	15
Table 7	DVI interface pin assignment	16
Table 8	Ethernet interface pin assignment.....	17
Table 9	USB interface pin assignment.....	18
Table 10	Jack plug pin assignment.....	19
Table 11	Interface options.....	20
Table 12	Module options	20
Table 13	Slot options	20
Table 14	USB interface pin assignment.....	21
Table 15	USB interface pin assignment.....	21
Table 16	RS232 interface pin numbering.....	22
Table 17	RS232 interface pin numbering.....	23
Table 18	Legend C6675 name plate.....	24
Table 19	C6675-0060 Minimum TwinCAT version	25
Table 20	Device component replacement recommendations	42
Table 21	Technical data of the battery	47
Table 22	Troubleshooting	55
Table 23	Technical data.....	56

Trademark statements

Beckhoff®, ATRO®, EtherCAT®, EtherCAT G®, EtherCAT G10®, EtherCAT P®, MX-System®, Safety over EtherCAT®, TC/BSD®, TwinCAT®, TwinCAT/BSD®, TwinSAFE®, XFC®, XPlanar® and XTS® are registered and licensed trademarks of Beckhoff Automation GmbH.

Third-party trademark statements

CFast is a registered trademark of CompactFlash Association.

Excel, IntelliSense, Microsoft, Microsoft Azure, Microsoft Edge, PowerShell, Visual Studio, Windows and Xbox are trademarks of the Microsoft group of companies.

MAX®, Stratix®, Cyclone®, Altera®, Agilex™, Arria®, Intel, the Intel logo, Intel Core, Xeon, Intel Atom, Celeron and Pentium are trademarks of Intel Corporation or its subsidiaries.

PCI Express®, PCIe®, PCI™ and PCI HOT PLUG™ are trademarks or registered trademarks and/or service marks of PCI-SIG.

More Information:

Beckhoff Automation GmbH & Co. KG
Hülshorstweg 20
33415 Verl
Germany
Phone: +49 5246 9630
info@beckhoff.com
www.beckhoff.com

